


PNP-7DI INTERFACE CABLE

**THIS CABLE IS TO INTERFACE THE ICOM'S
7 PIN ACC 2 TO THE AMERITRON ARB-704**



PNP-7DI

1. Connect the 5 pin end of the Plug and Play cable to the multi-port of the ARB-704.
2. Connect the 7 pin end of the same cable to the ACC2 jack of the Icom.
3. Connect a Phono cable from Amp jack of the ARB to Relay of the amplifier.
4. If using ALC connect a Phono cable from ALC jack of the ARB to ALC of the amplifier.

The power jack of the ARB is not used in this application.

The Radio jack on the ARB is not used in this application.

The jumpers inside the ARB-704 will stay at the factory setting. No change is to be make.

When the transceiver is placed into transmit, the light on the ARB should illuminate and the Amplifier should go into transmit mode.